
STEP 4: CONNECTING TO YOUR WI-FI NETWORK

- Ensure Wi-Fi is enabled on your device
- Go to **Wi-Fi settings** on your device and select the network name you set up in step 3.
- Enter the password you created.



HOW TO SET UP YOUR WI-FI UNIT.

Use this guide to set up one Deco Unit. If you have two or more units, the app will help you do the rest.



D tp-link

Got stuck or need a hand? Call us: 0800 438 669



IMPORTANT: YOU WILL NEED

1
2


NOW ACCOUNT NUMBER (find this in your welcome email or latest bill)

MOBILE DATA, OR A WI-FI CONNECTION (to download and log into the Deco app)



STEP 1: CONNECTING TO THE 'ONT'

(The ONT is the little fibre box that's already on your wall. It might look like this)




- Plug the provided Deco power adaptor into the wall and into the bottom of the first Deco unit. Power on.
- Plug one end of the provided ethernet cable into either the **GE1** or LAN1 port on your ONT. Plug the other end of the ethernet cable into either of the ports on the back of the Deco unit.
- At first the light on the top of the Deco unit will be yellow. It will change to a pulsing blue light when its ready for set-up. *Note: If the light is not pulsing blue, press the RESET button at the* bottom of the unit.

STEP 2: SETTING UP THE DECO APP

- Download the '**TP-Link Deco**' app onto your smartphone by scanning the QR code, or download it from Google Play or Apple Store.
- Open the app and create a TP Link account using your preferred email address and password.
- Activate the account and log in.





your devices to your network in Step 4.

Wi-Fi network. This is the name you will see when connecting