

NOW HUAWEI DG8245V QUICK START GUIDE

now




PACKAGE INCLUDES

- Huawei DG824 Wi-Fi Gigabit router
- Power Adaptor
- 2 x Ethernet Cable (RJ-45) (blue and yellow)
- 2 x Line Cable (RJ-11)



CONNECTING TO ADSL/VDSL



CONNECTING YOUR WIRELESS DEVICES TO THE ROUTER

The router comes shipped with the wireless function enabled so there is no configuration necessary in order to use the wireless.

1. Ensure Wi-Fi is enabled on your device (eg. computer/smartphone/gaming console).
2. Scan for wireless networks in your area and connect to the network name that matches the wireless network name found on the base of your router.
3. When prompted for your wireless security settings, enter the wireless LAN key listed on the base of your router.

CHECK ON THE BASE OF ROUTER

Wireless Security Settings

Wireless Network Name (SSID)

SSID 5G: Huawei - 5G - N3Ka

SSID 2.4G: Huawei - 2.4G - N3Ka

Wireless LAN Key


abcdefghijkl

- A** Connect the supplied RJ-11 (grey) cable to the DSL port on the back of the router and to the phone port that supplies your DSL service.
- B** Connect the supplied power adaptor to your router.
- C** Press the on/off button to power the router on.
- D** Connect your computer to your router using the supplied yellow ethernet cable (RJ-45).



CONNECTING TO FIBRE

STEP1: YOUR ONT SETUP




YOUR OPTICAL NETWORK TERMINAL

Your ONT (Optical Network Terminal) will have been installed on an internal wall by the fibre technician.

Connections A, B, C and D will have been made.

- A** Optical fibre connection.
- B** Power supply.
- C** Ethernet cable (blue) plugged into GE1 on your ONT, and connected to the WAN port on your router.
- D** POTS1 supplies your NOW phone line (if applicable). This is connected to either your phone or the back-feed jack point installed by the fibre technician.

STEP2: YOUR ROUTER SETUP



- E** Power supply.
- F** Ethernet cable plugged into WAN port on your router, and connected to GE1 on the ONT.
- G** Yellow Ethernet ports to connect your PCs and other network (yellow cable).
- H** The Phone1, Phone 2 and DSL ports are not used for a fibre connection.

CONNECTING YOUR WIRELESS DEVICES TO THE ROUTER

The router comes shipped with the wireless function enabled so there is no configuration necessary in order to use the wireless.

1. Ensure Wi-Fi is enabled on your device (eg. computer/smartphone/gaming console).
2. Scan for wireless networks in your area and connect to the network name that matches the wireless network name found on the base of your router.
3. When prompted for your wireless security settings, enter the wireless LAN key listed on the base of your router.

CHECK ON THE BASE OF ROUTER

Wireless Security Settings

Wireless Network Name (SSID)

SSID 5G: Huawei - 5G - N3Ka

SSID 2.4G: Huawei - 2.4G - N3Ka

Wireless LAN Key

abcdefghijk

0800 GET NOW
help@nownz.co.nz

now